

# TRAVERTINE PREMIERO™

Technical Data Sheet A.2



Travertine Premiero™ is quarried in the northern region of Iran. It is quarried in blocks, cut down to tile sizes, polished to a honed finish (satin matt) and filled mechanically with a mixture of calcite powder, kaolin, white cement and bonding agents. This mix is a durable, compatible filler that is colour matched to the stone. The stone and filler take 6-8 weeks to dry to final colour.

**Premiero™ Bianco** is the lightest selection of the Premiero™ range with the colour a light cream with almost no veining. The ratio of homogeneity is 90%. **Premiero™ Crema** offers light to medium shades within the range. The colour is light to medium cream with slight veining. The ratio of homogeneity is 70%. **Premiero™ Cappuccino\*** is the medium selection of the range. As the name suggests, the colour is medium coffee with slight veining. The ratio of homogeneity is 70%. **Premiero™ Nocé\*** is the darkest selection of the range with colour resembling a dark chocolate brown.

\*Both Premiero™ Cappuccino and Nocé are available in cross- or vein-cut, the cross-cut has a flower type pattern while vein-cut has a linear pattern.

# TRAVERTINE PREMIERO™

Technical Data Sheet A.2

## SIZES

300 x 300 x 10 mm	20mm slabs
305 x 305 x 10 mm	30mm slabs
400 x 400 x 10 mm	
457 x 457 x 12 mm	
610 x 610 x 15 mm	

## RECOMMENDED APPLICATIONS

This product is best suited for interior use on floors and walls. It can be used virtually anywhere in the house from kitchen or bathroom to lounge and dining room. The product can also be used externally for walls. The filled and honed tiles can be slippery under extremely wet conditions and are not recommended for exterior use on floors. Instead we recommend using tiles from the Rustico™ or Antico™ ranges (see Technical Data Sheets A.3 and A.4, respectively).

## LAYING RECOMMENDATION

- A 2-3mm joint between tiles
- The use of white tile adhesive
- MCC Travertine grout
- Existing expansion joints should be respected and not tiled over
- Use expansion joints as prescribed by architect or specialized tiler
- Tiles should be laid on a level and even screed which should have been cured for about one week prior to tiling
- Vein-cut tiles should be laid with veins in same linear direction

## PRODUCT CARE & MAINTENANCE

All natural stone should be sealed to prevent staining. We recommend the use of Delta Research Seal or Saf Seal as an anti-stain treatment. The product must be applied by professionals or under strict instruction as indicated by Delta Research. For everyday maintenance we recommend Delta Research Clean Stone or a neutral pH detergent. Do not use acid or alkaline detergents as repeated applications will damage the sealer, leaving the stone unprotected. Acid products can also erode the filler.